

## 01-025 Measuring oil consumption

### Special tools

Oil dipstick with millimeter scale  
for engines with oil suction

11004-7663



115 589 15 21 00

Oil dipstick with millimeter scale  
for engines without oil suction

11004-8082




110 589 11 21 00

Telethermometer



116 589 27 21 00

Valve for interrupting oil return  
flow from oil cooler



110 589 00 91 00

### Note

The oil consumption can be measured by means of oil dipstick with millimeter scale and the pertinent diagram on back of data sheet.

### Data sheets

Engine 110	Print no.
Engines with oil suction	800 99 403 00 German/English 800 99 403 01 French/Spanish
Engines without oil suction	800 99 227 00 a German/English 800 99 227 01 a French/Spanish

The measuring procedure is explained on front page of data sheet.

To avoid faulty measuring, check engine oil for dilution by fuel prior to measuring.

